



Company Name
Method Statement
Container Waste Preparation

Date Prepared:

Head Office: 42-44 Derby Road, Liverpool, L20 1AB

Tel: 0151 286 1055 Fax: 0151 286 1058 Email: info@euowaste.net Web: www.europeanwastesolutions.co.uk

Company Registration No: 4198942 Vat Registration No: 77887457

Waste Hierarchy: Prevention - Preparing for Re Use – Recycling – Recovery - Disposal

Method Statement

Procedure - Container Waste Preparation

Company -

Location -

Introduction:

This is a site-specific method statement undertaken prior to the activity commencing.

Objective:

Container waste removal

The waste must be prepared in a safe secure manner, in accordance with the Carriage of Dangerous Goods ("CDG 2009") SI 2009 No 1348

Management Controls:

To maintain a safe working environment the following must be adhered to:

✓ **Site Induction:**

To Mitigate Health & Safety risks

Clarify operatives understand their induction and meet the site compliance.

RAMS:

Monitor all operatives ensuring the RAMS are adhered too

✓ **Reporting:**

All accidents / spills or near misses **MUST** be immediately reported to the relevant authorities

Please Note:

Any waste generated must prepared in accordance with:

"The Carriage of Dangerous Goods and use of Pressure Equipment road regulations 2009 (CDG Regs)" and the "European Agreement (ADR)".

Personnel Requirements:

- ✓ Qualified Chemist
- ✓ Technically Competent operatives

Documentation:

- ✓ RAMS
- ✓ Inventory (If available)
- ✓ Conveyance Labels

Equipment:

Personal Protective Equipment:

- ✓ Safety foot wear
- ✓ Protective gloves
- ✓ Face Shield / Eye protection
- ✓ Hi visibility clothing
- ✓ Hard hat (Site specific)
- ✓ Fire Retardant Overalls
- ✓ Waterproof workwear
- ✓ Ear plugs (Site Specific)

Standard Equipment:

- ✓ Drum Key
- ✓ Pliers
- ✓ Stanley Knife
- ✓ Hammer
- ✓ Rubber Mallet
- ✓ Hack Saw
- ✓ 15mm Copper Tube
- ✓ Paint
- ✓ Paint Roller & Brush
- ✓ Conveyance Labels
- ✓ Refuge Bags
- ✓ Shrink Wrap

Additional Equipment:

- ✓ Visqueen Sheeting
- ✓ Sand
- ✓ Drum De-heading Tool
- ✓ Shovel
- ✓ Brush

Classification & Labelling:

Scope of Works

There must be No Smoking or Mobile Phones on site.

On arrival:

- ✓ Adhere to site speed restriction & park in contractor designated area(s)
- ✓ Report to site, sign in.
- ✓ Adhere to site Health & Safety rules at all time
- ✓ Ensure the site representative is familiar with the procedure
- ✓ Obtain permit (Site Specific)
- ✓ First aid facility on site would be utilised in the event of a accident/ incident.
- ✓ In the event of an emergency follow site evacuation procedure.
- ✓ Change into PPE
- ✓ Only utilised equipment brought on site as listed above under "Equipment"

Site Preparation:

- ✓ Prepare an area within the main bunded area by laying the vis-queen then use sand to create a temporary bund, if necessary the bund can be relocated as an alternative to moving any damaged packaging
- ✓ The temporary bund area will be utilised for re-packaging of any damaged containers preventing any flooring staining caused by spillage.
- ✓ The temporary bund will be cleared by utilising an open top 205Lt drum

Container Preparation:

- ✓ All Containers & Pallets will be checked visually for integrity, preventing leaks or spills whilst in transit
- ✓ Any damaged pallets will be replaced within the temporary bund reducing the risk of an uncontrolled spillage within the main bund
- ✓ Any damaged containers will be decanted into a secure and suitable replacement container
- ✓ Contents will be identified and classified prior to labelling
- ✓ Closure will be removed
- ✓ Container dipped with copper tubing identifying solid content and materials
- ✓ Closure replaced in preparation for labelling

Labelling:

All previous labels MUST be removed or painted over, allowing for clarity of the containers contents in the event of an accident

- ✓ Roller or paint brush existing labels, if difficult to remove
- ✓ New conveyance labels must be positioned in the centre of the container forward facing
- ✓ The labels must be clear and legible and stand out from the background

Secure Containers:

- ✓ Tie off one end of the shrink wrap to the bottom of one corner of a pallet
- ✓ Proceed to move around the pallet covering all the containers with an appropriate amount of shrink wrap to secure the containers in transit

On Completion:

- ✓ On completion, remove all equipment.
- ✓ Prior to leaving ensure area is clean & tidy
- ✓ Change out of PPE
- ✓ Sign off site proceed to notify all relevant personnel

I acknowledge this Method Statement and have read, understood and accept all information contained within this document

Signed for on behalf of the customer

.....

Print Name

.....

Dated

.....

I acknowledge this Method Statement and have read, understood and accept all information contained within this document.

Signed for on behalf of the European Waste Solution Ltd

.....

Print Name

.....

Dated

.....

Disclaimer
This Method Statement is offered as a service to users. European Waste Solutions Ltd assumes no liability from its use. It is the responsibility of anyone using the form to confirm the processed information prior to use.